

Installation:

RENEW™ CR should only be applied to a properly prepared substrate. Remove any material that interferes with bond including dust and dirt by brooming and vacuuming, including expansion joints. Expansion joints likewise should be marked to prevent being filled by RENEW™ CR.

Pour the mixed RENEW™ CR onto the "SSD" substrate. Then spread with a squeegee, or flat trowel using enough pressure to assure good contact with the entire surface then broom finish. Work in areas small enough for easy access for broom finishing without having to walk on the fresh RENEW™ CR. A broom finish needs to be applied within 10-15 minutes of application while the product is still fresh. Pour subsequent applications while the previous application is still wet. On vertical installations, such as stairs, trowel RENEW™ CR directly onto the properly prepared distressed area and finish as desired.

RENEW™ CR can be applied at a thickness of up to 1/2"

WARRANTY

PENETRON SPECIALTY PRODUCTS INC. warrants that the products manufactured by it shall be free from material defects and will conform to formulation standards and contain all components in their proper proportion. Should any of the products be proven defective, the liability to PENETRON SPECIALTY PRODUCTS INC. shall be limited to replacement of the material proven to be defective and shall in no case be liable otherwise or for incidental or consequential damages. **PENETRON SPECIALTY PRODUCTS INC. MAKES NO WARRANTY AS TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED.** User shall determine the suitability of the product for its intended use and assume all risks and liability in connection therewith.

P E N E T R O N S P E C I A L T Y P R O D U C T S

Penetron Specialty Products Inc.
45 Research Way, Suite 203
East Setauket, NY 11733, USA
+1 (631) 941-9700
penetronsp.com
info@penetronsp.com