

# Precast Construction

This section is intended as an informational resource to aid in specifying METROBRICK® Architectural Thin Brick. Please refer to specific installation and substrate product guides for instructions on using those specific products.

# Tilt-Up Construction

This section is intended as an informational resource to aid in specifying METROBRICK® Architectural Thin Brick. Please refer to specific installation and substrate product guides for instructions on using those specific products.

METROBRICK® is a thin, fired clay unit used as a wall covering and providing the appearance of conventional brick masonry. Metro Brick can be either thin-set or mortar-set in the field using traditional tile setting and grouting methods or various types of panel systems.

## Thin Set & Mortar Set

This section is intended as an informational resource to aid in specifying METROBRICK® Architectural Thin Brick. Please refer to specific installation and substrate product guides for instructions on using those specific products.

METROBRICK® is a thin, fired clay unit used as a wall covering and providing the appearance of conventional brick masonry. Metro Brick can be either thin-set or mortar-set in the field using traditional tile setting and grouting methods or various types of panel systems.

METROBRICK® can be used on a variety of interior and exterior wall substrates such as concrete, concrete unit masonry, gypsum sheathing, cementitious backer board, and plywood.

METROBRICK® can be used to shop or field fabricate a variety of modular wall panels faced with thin brick veneer.

Methods W211, W221, W222, W223, W231, W241, W242, W243, W244C, W244F, W245, W246 and W247 may be used for dry interior applications. Some of these methods are suitable for interior wet applications when the proper water resistive barrier is used.

Flashing, expansion joints (soft joints) and consideration for climate and exposure should be considered when choosing the correct method to be used.